

260 108

Klavijaturni prekidač




3 dirke
Obod

EI, Niš

260 109

Klavijaturni prekidač



4 dirke
EI

EI, Niš

260 110

Klavijaturni prekidač



5 dirki
EI

EI, Niš

260 111

Klavijaturni prekidač



4 dirke
EIDA - beli

EI, Niš

390 111

Ručica vrata veš mašine



Gorenje
Model: PS663
Komplet

390 112

Ručica vrata veš mašine



EI
Model: Pevac

390 113

Ručica vrata veš mašine



Gorenje
Okrugla sa dugmetom
Model: PS100

390 114

Ručica vrata veš mašine



Obod stari tip
Komplet
Model: K5

390 115

Ručica vrata veš mašine



Obod, novi tip
Komplet
Model: 600/6000

390 116

Ručica vrata veš mašine



Gorenje Olimpik
Model: PS400 International